

## True North T-1 RIT BAG - LOAD INSRUCTIONS

1. Remove the cone from the top of the bag by releasing all three buckles. Put top aside.
2. Locate metal cam-lock buckle at top of bag. Press down on lever and open cord as far as possible.
3. With the first stage regulator removed, insert the air cylinder into the opening.
4. Now cinch the draw-string tight.
5. To get a snug fit you may need to slide the fabric away from the buckle once or twice until you get a tight fit.
6. Next we'll stow the hoses. Locate the flaps on the side of the bag which are near the top and side by side. Open both flaps then undo the piece of web with Velcro holding the flaps together.
7. Now take a moment to attach the primary regulator to the air cylinder.
8. There are two pockets, one for the transfill and one for the second stage regulator. Place the transfill hose in one pocket with the transfill fitting at the top of the pocket where it will be easy to grab when the pocket flap is opened. Place the low pressure hose in the second pocket.
9. For SCBA systems that require more space (such as the MSA models) you can undo the snap and the strip of Velcro between the two hose pockets to give you more room.
10. Re-fasten the webbing between the two flaps so the second stage regulator hose is behind the flaps. Fasten the flaps.
11. If you want to have the second stage regulator easily accessible but not attached to the mask you can place the regulator in the holder.
12. You can connect the regulator to the face piece and stow the face piece in the cone which forms the top of the bag.
13. Replace the cap on the bag by first reconnecting the seatbelt style buckle, and then reconnecting the two other buckles.
14. The T-2 RIT bag has three tool pockets. The middle tool pocket is well suited for light sticks.
15. The lower hand tool pockets are ideal for metal shears, dykes, etc.
16. The T-1 RIT Bags are equipped with a removable rope and tool bag. To load the rope, unzip the rope bag from the main bag.
17. Unzip the top of the rope bag and feed one end of the rope through the bag and out through the rope port at the bottom of the bag.
18. Flake rope into the bag and then feed the remaining end of the rope out through the port at the top of the bag
19. Zip the bag closed.
20. The T-1 contains an extra tool pocket that runs the full length of the bag. This pocket can hold up to an 18" set of bolt cutters.
21. The daisy-chain between the lower tool pockets is for clipping on TICs, search line bags or other equipment.
22. After loading the rope and tools, zip the rope bag back onto the main bag.

**END**